



Albero uscita
Output shaft
Abtriebswelle

Albero entrata
Input shaft
Antriebswelle

60/2-60/3	A	D	E	d	F1	F2	F3	F4	V	N	C	M	P	S	S1	U/n°
/2	606	406	80	38	41	10	11	50	M10							
/2F-350	606	406	80	38	41	10	11	50	M10	250	130	300	350	18	5	18/4
/2F-450	606	406	80	38	41	10	11	50	M10	350	190	400	450	18	5	18/8
/3	568	398	50	24	27	8	5	40	M8							
/3F-350	568	398	50	24	27	8	5	40	M8	250	130	300	350	18	5	18/4
/3F-450	568	398	50	24	27	8	5	40	M8	350	190	400	450	18	5	18/8